SRT Vault Keypad Orientation Instructions

S & G Spartan Lock

1. Remove the S&G plastic LOGO located at the bottom of the lock.
2. Remove the screw from behind the LOGO.
3. The Keypad can now be removed from the lock. Also, the outer ring can be removed.
4. There are two screws on the inside of the keypad assembly, remove them.
5. There are 4 holes located behind the keypad assembly. Rotate your lock 90 to 180 degrees to the desired orientation.
6. Re-install the two inner screws,
7. Reverse assemble the keypad. Please note the outer ring can be re-installed after the keypad is in place. The blue tab on the ring may need to be pulled out a ¼"for re-assembly.